



MINARELLI MNZ01

VREF +5V	A1	CN
NEUTRAL	A2	Z
CAN H	A3	CL
CAN L	A4	CL
SPEED	B1	IGL
STAND	B2	IGL
T AIR	B3	IGL
CAN L	B4	IGL
LAMBDA 1	C1	IGL
C2		
RUNSTOP	C3	
FAN RELE	C4	V
D2		
TEMP MOT	D3	SN
D4		
INI 1	E1	SS
MAP SENS	E2	SS
K LINE	E3	SS
E4		
IDLE	F1	MR
F2		
F3		
F4		
TPS	G1	RL
PICKUP GND	G2	LV
SENS GND	G3	GV
G4		
PICKUP	H1	IC
H2		
MIL	H3	BN
H4		
START REL	J1	ZN
J2		
J3		
J4		
HEATER 1	K1	HN
HEATER 1	K2	HN
K3		
K4		
VVA - H	L1	BV
L2		
GND	L3	N
COIL	L4	SS
VVA - L	M1	ZG
FUEL PUMP	M2	NZ
VKEY	M3	MB
VBATT	M4	R

ABS UNIT

1	PCC 0
2	CAN H
3	WL ABS
4	IGN
5	OBD K
6	REAR SIG
7	
8	FRONT SIG
9	GND
10	CAN L
11	ABS MODE
12	TACHY
13	PCC 2
14	REAR GND
15	PCC 1
16	FRONT GND
17	KL30
18	

OBD

2	CAN H
5	CAN L
1	GND
3	+V BATT
4	OBD-K

FUSIBILI

MB	7.5A (F7)	MB
RG	7.5A (F6)	S
GN	5A (F5)	SC
RS	30A (F4)	SC
M	5A (F3)	M
R	7.5A (F2)	R
R	7.5A (F1)	R